

DIRECTIONS:FOR MUCK BUCKET CART

1/PLACE FIG A (SQ.PC.TUBING) AND ATTACH TO FIG.B TO TOP HOLES OF TUBING.SLIP BOLT THROUGH AND ATTACH NUT. SEE PICTURE BELOW

2/PLACE FIG.C AXLE ASSEMBLY ON TOP FIG B. INSERT BOLT ON BOTH SIDES OF TUBING. INSERT BOLT FRONT SECTION OF TUBING.

3/PLACE FIG. D HANDLE WITH RUBBER GRIP: 2 HOLES END :AND ATTACH TO FIG. B INSERT THE 4 BOLTS AND NUTS.

4/TIGHTEN EVERYTHING INSERT 8" SOLID TIRE ON AXLE PLACE WASHER OVER AXLE AND INSERT COTTER PIN.

