


HOW TO FIT YOUR HORSEWARE® BLANKET



Measure from (A) at the center point of the chest, over the high point of the shoulder, and to (B) at the rear of the hind leg. Rambo®, Rhino® and Amigo® blankets are sized in three inch increments. Amigo® Stock Horse is sized in two inch increments. If you measure between sizes, round down for Rambo® blankets and measure up for Rhino®, Amigo® and Amigo® Stock Horse blankets. When you have the measurement, choose the nearest from the table below.

- Make sure that the tail is lifted over the fillet strap and that the strap is securely attached on both sides. This will prevent the blanket from blowing forward. Where possible pull the tail through the strapping on the inside of the tail flap.
- When closing the surcingles on a blanket secure the middle one 1st and then cross over the 2 outer surcingles. Make sure the surcingles hang at least 4 to 8 inches below the horse's belly.

BLANKET SIZE CHART

Measurement from A to B			EU Back Seam Equivalent
CM	INCHES	FEET	CM
114	45	3'9	75
122	48	4'0	80
130	51	4'3	85
137	54	4'6	90
145	57	4'9	95
152	60	5'0	100
160	63	5'3	110
168	66	5'6	115
175	69	5'9	125
183	72	6'0	130
191	75	6'3	140
198	78	6'6	145
206	81	6'9	155
213	84	7'0	160
221	87	7'3	165
229	90	7'6	170

NECK COVER SIZE CHART

Neck Cover	XXXS		XXS		XS		S	
Size	45"	48"	51"	54"	57"	60"	63"	66"
Neck Cover	M			L			XL	
Size	69"	72"	75"	78"	81"	84"	87"	90"